

Dear Customer,

Thank you for purchasing our Wire300 machine. The following are basic installation and operation instruction for the Wire300 machine. For advanced punching and binding, please contact DFG.


Installation

Remove the blue knob from machine. Install the punch handle. Install the blue knob back to machine.



Remove the blue knob,
Install the punch handle
and replace blue knob

How to Punch



1. Set the side guide to center the sheet for punching

2. Select the punch margin (tip – the thicker the book, the larger the punch margin can be. However, you can use a small punch margin for any book)

3. Make sure your sheets are all the way inside, against the back wall, and then move sheets to the left side against the side guide. Pull the punch handle to punch the sheets.

How to Close Wire

1. Place sheets into wire, then push back on the punching handle to close wire